


CLEANLINE AM



High strength alkaline circulation cleaner suitable for the removal of fat and protein deposits in milking equipment and bulk tanks

Product benefits:

- Powerful cleaning action
- High levels of sequestrants to aid fat and protein removal
- For use with hot water

Ordering information:

- 5817 – 25 litre (50 washes)
- 5818 – 200 litre (400 washes)
- 5819 – 1000 litre (2,000 washes)

Shelf life:

- 1 year from date of manufacture

Storage instructions:

Store between 0° to 25°C
Keep out of direct sunlight



Product application:

1. After milking rinse milking equipment with cold water using at least 10 litres per unit.
2. Make a 0.5% solution at the rate of 500ml to 100 litres water at 80°C, using at least 10 litres water per unit.
3. Circulate solution for between 7 and 10 minutes or until the water temperature drops to 54°C.
4. Run to waste.
5. Rinse with clean cold water using at least 10 litres per unit.